


MODBUS Trigger Configuration

This functionality is available using Firmware $\geq$ 6233.

There are two ways to start the motion using MODBUS communication:

Item
Using broadcast message (special message to send using RS485 communication)
Writing the modbus sync signal register
Writing the modbus sync signal register with id address equal to 0
Writing the modbus sync register with the table index value

First of all you have to configure the motion controller to receive the motion trigger using modbus trasmission selecting the right motion trigger type for the rows you want to trigger.



Using broadcast message

If the motors to synchronized are more than 1 and you want to send just one message, you have to use this method.

In particular you have to send two characters on the RS485 MODBUS like in this table. The motor will not reply to this message to avoid collision on the modbus.

1st character	2nd character
0x00	0x80

In this way all the nodes will received the trigger command the trasmission time is minimized.

Writing the modbus sync signal register

If the motor involves in the synchronization is just one you can write a MODBUS register to send the trigger signal.

The Modbus register is **4622**. When this address is write with the value = 1 and then to confirm again the register 4622 to zero.

Writing the modbus sync signal register with id address equal to 0

If the motor involves in the synchronization are more than 1 you can write a MODBUS register to send the trigger signal.

If the address of the modbus write is 0 (node id = 0), the write is receive from all the nodes on the bus and the synchronization starts accordingly fro all nodes.

Writing the modbus sync signal register with the table index value

Instead of the value 1 and 0, the register 4622 can contains the value of the table row to triggered. Also in this case the address can be 0 in case of broadcast message to all the motors connected on the same modbus rtu bus. In order to configure this mode please set the trigger to MODBUS_table.

The screenshot displays the NILAB Starter Commissioning Tool interface. The main window is titled "Motion controller" and shows various configuration tabs. The "Motion Table" tab is active, displaying a table with columns: Index, Motion type, Position, Acceleration time or deceleration time, Constant speed time, Deceleration time, Waiting, and Trigger mode. The table lists 10 rows of motion profiles. The "Trigger mode" column for the first row (Index 1793) is set to "MODBUS_table".

Index	Motion type	Position	Acceleration time or deceleration time	Constant speed time	Deceleration time	Waiting	Trigger mode
1793 0	Trapezoidal	10,000 mm	100 msec	0 msec	50 msec	20 msec	MODBUS_table
1804 1	Trapezoidal	50,000 mm	100 msec	0 msec	50 msec	20 msec	
1815 2	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1826 3	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1837 4	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1848 5	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1859 6	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1870 7	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1881 8	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	
1892 9	None	0,000 mm	0 msec	0 msec	0 msec	0 msec	

The interface also includes a "Motion mode" section on the right, a "Motion parameter" section with "Evaluate motion profile" button, and a "Digital input and output Configuration" section. The "Motion control" section at the bottom shows buttons for "START MOTION", "STOP MOTION", "Modbus SYNC by Register", and "Modbus Broadcast SYNC".

Testing the synchronization using NILAB Starter

You can testing this functionality using the NILAB Starter software using the two button on the motion controller.

With the button Modbus SYNC by register the interface write 1 and 0 in sequence on the 4622 modbus address.

With the button Modbus Broadcast SYNC the interface will send the two characters corresponding to

broadcast message on the Modbus serial.

From:

<https://dokuwiki.nilab.at/> - **NiLAB GmbH**
Knowledgebase

Permanent link:

https://dokuwiki.nilab.at/doku.php?id=en:nilab_starter:modbus_sync

Last update: **2026/09/11 07:58**

