




# External braking resistor

This servo amplifier, except 30/60A and 42/84A sizes, is equipped with internal braking resistor. To disconnect the internal resistor from the brake circuit in order to use an external resistor remove the jumper between terminals 7 and 8 of C4 connector and connect the external resistor as shown. The admitted values and the braking power concerning the external braking resistor are located on the table in paragraph 4.2.

 <b>CAUTION</b>	Lower value resistors could irreversibly damage the servo amplifier
 <b>CAUTION</b>	Considering that the resistor's case can overcome easily the 80°C will be necessary to indicate with warning labels the presence of dangerous high temperature and protect from accidental contacts the electrical connections



From:  
<https://dokuwiki.nilab.at/> - NiLAB GmbH  
Knowledgebase

Permanent link:  
[https://dokuwiki.nilab.at/doku.php?id=mbd\\_servo\\_drive:braking\\_resistor](https://dokuwiki.nilab.at/doku.php?id=mbd_servo_drive:braking_resistor)

Last update: 2023/09/21 07:16

