

CanOPEN over EtherCAT

Mode of operation:

https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_modes

Standard PDOs: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:can_open_pdo

Standard SDOs: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_sdo

Errors Codes: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_error

From:

<https://dokuwiki.nilab.at/> - **NiLAB GmbH**

Knowledgebase

Permanent link:

<https://dokuwiki.nilab.at/doku.php?id=epulse:coe>

Last update: **2026/03/10 15:22**

