


# Kinetix 5700 Rockwell servo drive

In order to use with Kinetix 5700 servo drive, please use the Hiperface to DSL converter 2198-H2DCK in combination with our DE21500780-5M (5 meter Revenc encoder cable for Kinetix Servo drive) with DSUB9 pin male.

Signal	DE21500780 D-SUB 9 Pin	2198-H2DCK Terminal block
SIN-	6	2
SIN+	3	1
COS-	2	4
COS+	1	3
DATA-	5	10
DATA+	4	5
GND	7	6

## Connector Data



From:  
<https://dokuwiki.nilab.at/> - NiLAB GmbH  
Knowledgebase

Permanent link:  
[https://dokuwiki.nilab.at/doku.php?id=reverso\\_encoder:rockwell\\_servo\\_drive](https://dokuwiki.nilab.at/doku.php?id=reverso_encoder:rockwell_servo_drive)

Last update: 2024/09/07 14:45



