

Encoder-Pinbelegung

Resolver-Feedback

Encoder-Typ: Resolver 2p 7V 10KHz

RESOLVER CONNECTION			
Function	M15 –12+3p	M17 – 17p	M23 – 12p 20°
Ref+	10	10	10
Ref-	7	7	7
Cos+	2	2	2
Cos-	1	1	1
Sen+	11	11	11
Sen-	12	12	12
PTC / PT1000+	8	8	8
PTC / PT1000-	9	9	9

TTL-Encoder

TTL ENCODER CONNECTION			
Function	M15 –12+3p – SIZE 0 ¹⁾	M17 – 17p	M23 – 17p
+5VDC	B	10	10
GND	A	7	7
A+	11	1	1
A/	12	2	2
B+	1	11	11
B/	2	12	12
Z+	3	3	3
Z/	10	13	13
U+	4	4	4
U/	-	14	14
V+	6	5	5
V/	-	6	6
W+	5	16	16
W/	-	15	15
PTC / PT1000+	8	8	8
PTC / PT1000-	9	9	9

BISS-C-Encoder

Encoder-Typen:

ELM35 :

<https://www.sick.com/at/de/catalog/produkte/motion-control-sensoren/motor-feedback-systeme/elsel-m35/c/g584054>

<i>BISS-C ENCODER CONNECTION (additional BISS-B analogic signals in brackets)</i>			
<i>Function</i>	<i>M15 – 12+3p</i>	<i>M17 – 17p</i>	<i>M23 – 17p</i>
+5V _{Dc}	10	10	10
GND	7	7	7
(A+)	1	1	1
(A-)	2	2	2
DATA+	3	3	3
CLOCK+	5	5	5
(B+)	11	11	11
(B-)	12	12	12
DATA-	4	13	13
CLOCK-	A	14	14
GND BAT (0V SENSE)	B	15	15
+VBAT (5V SENSE)	C	16	16
PTC / PT1000+	8	8	8
PTC / PT1000-	9	9	9

Endat-Encoder

Encoder-Typen:

EQI1131 Endat 2.2: <https://www.heidenhain.com/service-support/infobase/1164811-05>

EQI1130 Endat 2.1: <https://www.heidenhain.com/service-support/infobase/1164813-04>

<i>ENDAT ENCODER CONNECTION 2.2 (2.1)</i>			
<i>Function</i>	<i>M15 – 12+3p</i>	<i>M17 – 17p</i>	<i>M23 – 17p</i>
+5V _{Dc}	10	10	10
GND	7	7	7
(A+)	1	1	1
(A-)	2	2	2
DATA+	3	3	3
CLOCK+	5	5	5
(B+)	11	11	11
(B-)	12	12	12
DATA-	4	13	13
CLOCK-	A	14	14
0V SENSE	B	15	15
+5V SENSE	C	16	16
(PTC / PT1000+)*	8	8	8
(PTC / PT1000-)*	9	9	9

*Thermal sensor pins are inserted into the connector only with Endat 2.1, with Endat 2.2 sensor must be read from encoder DATA

SIN/COS-1Vpp-Encoder

<i>SIN/COS 1Vpp ENCODER CONNECTION</i>		
<i>Function</i>		<i>M23 – 17p</i>
+5VDC		10
GND		7
A+		1
A-		2
R+		3
D-		4
C+		5
C-		6
B+		11
B-		12
R-		13
D+		14
OV SENSE		15
5V SENSE		16
PTC / PT1000+		8
PTC / PT1000-		9

Hiperface-Encoder

Encoder-Typen:

SEL37 :

<https://www.sick.com/at/de/catalog/produkte/motion-control-sensoren/motor-feedback-systeme/seksel/c/g575659>

SKM36:

<https://www.sick.com/at/de/catalog/produkte/motion-control-sensoren/motor-feedback-systeme/skssk/m36/c/g215684>

SEM70:

<https://www.sick.com/at/de/catalog/produkte/motion-control-sensoren/motor-feedback-systeme/sessem/sem70-hn025ak22/p/p512349?tab=detail>

<i>HIPERFACE CONNECTION</i>			
<i>Function</i>	<i>M15 – 12p</i>	<i>M17 – 17p</i>	<i>M23 – 17p</i>
US	10	10	10
+ SIN	8	1	1
- SIN	4	2	2
+ COS	9	11	11
- COS	5	12	12
GND	11	7	7
+ DATA	6	3	3
- DATA	7	13	13
PTC / PT1000+	1	8	8
PTC / PT1000-	2	9	9

DSL-Encoder

Encoder-Typen:

EKM36 :

<https://www.sick.com/ag/de/catalog/produkte/safety/sichere-motor-feedback-systeme/eksekm36-s/ekm36-2kf0b020a/p/p478044>

EKS36:

<https://www.sick.com/ag/de/catalog/produkte/motion-control-sensoren/motor-feedback-systeme/eksek36/eks36-0kf0b018a/p/p477845>

DSL ENCODER CONNECTION		
Function	M15 – 4+5p	M23 – 4+5p
U phase motor	A	A
V phase motor	C	B
W phase motor	B	C
+24VDC Brake	1	G
0V Brake	2	F
Earth		
DSL+	3	E
DSL-	4	H

From:
<https://dokuwiki.nilab.at/> - **NiLAB GmbH**
Knowledgebase

Permanent link:
https://dokuwiki.nilab.at/doku.php?id=de:mbm_motors:encoder_option

Last update: **2026/09/11 19:52**

